

Name **Rome 41**

BUFFER Mode :

Distance - Ft.

OIL Mode :

Distances - Ft.

left outside :

left track :

left inside :

right inside :

right track :

right outside :

Transfer Rate %

SPEED SETTINGS:

Travel

Condition

Strip

Pass 1

Double	
Forward	Reverse
41.0	41.0

Double	
Forward	Reverse
25.0	35.0
29.0	35.0
33.0	35.0
33.0	35.0
29.0	35.0
25.0	35.0
20	25

Pass 2

Double	
Forward	Reverse
30.0	20.0

Double	
Forward	Reverse
12.0	8.0
25.0	18.0
27.0	20.0
27.0	20.0
25.0	18.0
12.0	8.0
65	80

Short Run

Mode	Off
Turn-around Distance	0.0 Ft.

Stripping

Mode	Full
Start	0.0 Ft.
Cleaner Pad Distance	61.5 Ft.
Vacuum	On Start

Cleaner Flow

In oil	100 %
Back lane	25 %

Pass 1

Forward	Reverse
Medium	Medium
Medium	Medium
Medium	

Pass 2

Forward	Reverse
Medium	Medium
Medium	Medium

Use #4 foam in middles,

#6 in track and #8 in outsides